

ZWF845B4PW

Reduce time, maximise performance, with Quick Programmes

The Quick Programmes are built for mid-week washes and smaller loads. Choose between the Easy 60-minute wash, Rapid 30-minute cycle, and the 14 -minute Refresh wash. For great results, at a time that suits you.

Product Benefits & Features

Quick Programmes, more time for you

The Quick Programmes are built into the machine so you can get more done on busy days. The Easy 60-minute cycle is a great all-rounder, while the Rapid 30-minute programme is on hand for smaller loads. And for an extra quick treatment, the 14-minute Refresh cycle can be selected, too.

Give your clothes an effective wash with CleanBoost

The ČleanBoost 60°C washing programme provides steam at the end of the cycle, to give your clothes a hygienic and efficient clean. This helps reduce bacteria and allergens from your clothes, and supports better laundry hygiene.

- · Maximum spin speed: 1400 rpm
- · Washing capacity: 8 kg
- · Washing programs: ON/OFF, Eco 40-60, Cottons, Synthetics, Delicates, Wool, Denim, Sport Wear, Spin/Drain, Rinse, Dark Clothes, CleanBoost, 14min Refresh, 30min Rapid, 60m EasyWash
- Out of balance control of the drum load
- · Fuzzy Logic technology, adapting to the load
- Delay start optionAnti-foam rinse system
- · Child lock
- · Feet: 4 adj feet
- Anti-flood protection
- 52 I / 0.96 kWh for standard programme

Reduce the time of cycles, with FlexiTime

You're always in charge with the FlexiTime button, which lets you speed up cycles to suit your schedule. Tap once to activate, and again to subtract some cycle time. You can do this three more times - every time chopping off a bit more of the cycle's overall duration.

Fewer creases, with Easylron

The Easylron programme applies extra care to your laundry cycles, reducing wrinkles and creases in clothes. During the cycle, the drum alternates the direction of its rotation, letting clothes move more freely. So you spend less time standing over the ironing board.

Delay Start, for convenient washing

Delay Start gives you extra control over your washing machine, so clothes can be laundered on your schedule. You can set the delay in one hour intervals, from 2 – 20 hours, so wet clothes are never left sitting in the drum on those busy days.



ZWF845B4PW

Р	ro	dι	ıct	Sı	рe	cif	ic	at	io	n

Product Installation Product Typology Product Classification	Free_Standing Front_Loaded_Full_Size Core	Program list	ON/OFF, Eco 40-60, Cottons, Synthetics, Delicates, Wool, Denim, Sport Wear, Spin/Drain, Rinse, Dark Clothes, CleanBoost, 14min Refresh, 30min Rapid, 60m EasyWash		
Installation	FS				
Washing technology	Eco flap	Indicator programme	LCD		
Rinse system	Anti-foam system	Spin speed	1400		
Cabinet type of	HEC 54 XL	Indicators display	Digit LED		
Design family	SAFFRON		Temperature 1 levels, Temperature 2 levels, Temperature 3 levels, Temperature 5 levels, Cold, Spin 1, Spin 2, Spin 3, Spin 4, No spin, Rinse hold, Prewash, Extra rinse, Easy ironing, Silent,		
Design level	Z 4				
Main colour	White	Indicators other			
Panel colour	White				
Front door	RIM XL W				
Porthole type of	RIM XL W	Display type	Start/Pause Digit LED		
	Temperature selection, Spin selection,	Display type	ū		
Push button functions	FLEXITIME, Delay start, Prewash,	Height total	847		
	Extra rinse, Easy ironing, Silent,	Width mm	597		
Duck button functions number of	Start/pause	Depth mm	568		
Push button functions number of	9	Cabinet material	Steel		
Knob/Command functionality	Program	Tub material	Carboran		
Knob/Command functionality number of	1	Drum volume	53		
-		Washing capacity (kg)	8		